



Packer Repair Parts : Brown Husky

Replacement Parts

| Part No. | Casing Size | Casing Weight | O.D. | I.D. | L. |
|----------|-------------|---------------|-------|-------|-------|
| BH-278 | 2 7/8" | 6.4# | 2.27 | — | — |
| BH-350 | 3 1/2" | 7.7# - 10.2# | 2.77 | 1.685 | 3.905 |
| BH-400 | 4" | 9.5# - 11.6# | 3.25 | — | — |
| BH-450 | 4 1/2" | 10.5# - 13.5# | 3.75 | 2.78 | 3 |
| BH-450 | 4 1/2" | 10.5# - 13.5# | 3.75 | 2.78 | 3 |
| BH-502 | 5" | 15# - 18# | 4.125 | 3.015 | 2.875 |
| BH-550 | 5 1/2" | 13# - 15# | 4.812 | 3.32 | 2.96 |
| BH-551 | 5 1/2" | 15# - 17# | 4.718 | 3.32 | 2.96 |
| BH-552 | 5 1/2" | 17# - 20# | 4.625 | 3.32 | 2.96 |
| BH-553 | 5 1/2" | 20# - 23# | 4.5 | 3.32 | 2.96 |
| BH-700 | 7" | 17# - 23# | 6.187 | 4.075 | 3.61 |
| BH-701 | 7" | 23# - 26# | 6.062 | 4.075 | 3.61 |